

Installation

Hush Shutter

Door Jamb Installation Procedure

1. Place female section with door hung in opening.
2. Align door in jamb, tack in place with 40x25mm galvanized flat head clouts or 8g x 1 3/4 CSK particle board screw.
3. Adjust if required by hitting clout head or screw with nail punch.
4. Complete fixing as per diagram.
5. Place fox wedges - nail/screw.
6. Fit male side - nail or screw in place.
7. Clip on architraves to complete.

Notes:

- This trim size gives a 25mm gap under the door before flooring fitted.
- See also Hush Shutter Door Jambs - Hinge Fixing Details.
- For full height doors or solid core doors, 4 hinges may be required, wedge accordingly.
- Standard and heavy duty jambs available.

